

# WRX<sub>TRA</sub>

## ACC-1001 Oil Temp Sender Plug Installation Instructions

---

**IMPORTANT!** Read these instructions thoroughly before installing or using this product.

### 1. Introduction

Thank you for purchasing a WRXtra Oil Temp Sender Plug. Please read these instructions carefully to ensure optimum product performance. This product is designed to be used with oil temperature senders that have a 1/8" NPT male thread. It is intended for use in the Subaru Impreza or any other car with an M20x1.5 (14mm length) threaded oil drain.

### 2. Contents of package:

- (1) Oil Temp Sender Plug
- (1) Oil Plug Gasket
- (1) Installation Sheet



### 3. Tools Required:

- 17mm wrench
- TFE paste
- Appropriate wrench for sender (varies)



### 4. Preparing for Installation

1. Apply TFE paste to sender threads.



2. Thread sender into WRXtra plug until hand tight.



3. Using a 17mm wrench on the plug and the appropriate wrench on the sender, tighten one to two additional complete turns until tight.

4. Allow TFE paste to set per manufacturer's instructions.



## 5. Installation

**NOTE:** It is recommended that you install the new WRXtra plug and sender assembly during a routine oil change.

1. Following the manufacturer's recommended procedure, remove the drain plug and drain the engine oil into an appropriate container.
2. Clean the drain hole and surrounding areas of oil.
3. Using the new gasket, install the WRXtra plug and sender assembly in the drain hole and torque to the manufacturer's specification.
4. Fill engine with the appropriate amount of manufacturer recommended oil.

You are now ready to wire your oil temperature gauge to your sender.

This document is available online at <http://www.wrxtra.com> in the Documentation section.